


# COD (Connect On Demand)

In COD mode, the ezTCP functions as a client.

When data of the pre-specified size [WATER MARK] comes to the serial port, the ezTCP attempts a TCP connection to the TCP port [PEER PORT] of the preset host IP [PEER IP ADDRESS]. If the remote host accepts the TCP connection, TCP connection will be established. Data coming to the serial port after connection establishment is TCP/IP-processed and transmitted to the remote host. And, data coming from the remote host is TCP/IP-processed and transmitted to the serial port for data communication.



Sollae Systems Co., Ltd  
<http://www.eztcp.com>

sales: [sales@sollae.co.kr](mailto:sales@sollae.co.kr)

technical support: [support@sollae.co.kr](mailto:support@sollae.co.kr)